


.....**FA700KP**
Touch Screen
Keypad



Installation and
Set-Up Guide

.....




K0977-1 9/03 Rev. A


1 R T L A T S T F


T O U C H S C R E E N


SCREEN

Ready To Arm

 AWAY

 STAY


 NIGHT


 MORE CHOICES


Arm Multi-Partitions


P1 Sat 1/1/03 1:52 PM


Ready To Arm

 SHOW ZONES

 CONSOLE MODE

 EVENT LOGS

 OPERATING MODES

 SETUP

P1 Sat 1/1/03 9:10 AM

SCREEN

Ready To Arm

1	2	3	Enter Authorized Code:
4	5	6	
7	8	9	
0	<div style="border: 1px solid black; padding: 5px; display: inline-block;">CLEAR</div>		

FA700KP Installation and Setup Guide

LED	DESCRIPTION
ARMED	ON – Security system is armed. OFF – Security system is not armed.
READY	ON – Security system is disarmed and ready to arm. OFF – Security system is armed or disarmed but not ready. If disarmed, faults or troubles are present.
MESSAGE	FLASHING – The FA700KP contains message(s) for the User OFF – No messages.

Front Panel Buttons

BUTTON	DESCRIPTION
HOME	Used to return to the HOME screen display from any sub-menus.
FUNC	Reserved for future use.
PANIC	Used to display the EMERGENCY screen (Fire or Panic signal generation).
BACK	Used to exit the current screen display and return to the prior screen display.
▲	Used to scroll through screen lists in an upward direction.
▼	Used to scroll through screen lists in a downward direction.