

Ademco Vista 15 P / First Alert 148 CP

Zones - 40 Total

Wireless - Yes, Zones 09 to 34 + 8 Keyfob Zones (Zones 49 to 56)

Batteries - 12 volt Rechargeable inside main Panel, AC Transformer 16 volts

Door/Windows	3-Volt Lithium
Motion Sensor	2 3-Volt Lithium
Smoke Detector	2 9-volt Alkalines
Remote Keypads	3-Volt Lithium
Keyfobs	3-Volt Lithium
Remote Panics	9-Volt Lithium

Downloadable - Yes

Partitions - 1

Panic Buttons - Police Panic - \* and #

Fire Panic - 1 and \*

Medical Panic - 3 and #

Status - Press \* if keypad shows NOT READY to view open zones

Arm Away - 4-digit code + 2 (AWAY) to arm everything

Arm Stay - 4-digit code + 3 (STAY) to arm all but motions

Instant Arm - 4-digit code + 7 (INSTANT), this also bypasses motions

Max Arming - 4-digit code + 4 (MAX) and everything arms instant

Disarm - 4 digit code + 1 (OFF)

Silence Alarm - 4-digit code + 1 (OFF) twice to turn off siren and reset display (If code is entered wrong, wait 2 or 3 seconds then try again)

Bypass - 4-digit code + 6 (BYPASS) + zone (01, 02 03 etc)  
(keypad will beep, BYPASS + Zone should show, arm system)

Quick Bypass - User Code + 6 + # (Bypasses all open Zones)

Alarm Memory - See Event Buffer

Reset Smoke - 4-digit code + 1 (OFF) twice to turn off siren and reset smoke (If this does NOT reset smoke detector set for service, smoke is bad)

Door Chimes - 4-digit code + 9 (CHIME)

Quick-Arm # + 2 for AWAY, # + 3 for STAY

Phone Test - 1. 4-Digit Code + 5 (TEST) + 1

2. Keypad will send test signal

If successful keypad will show "Phone Okay" or "Cd"

If unsuccessful keypad will show "Comm Failure" or "FC"

Test Sensors - 4-Digit Code + 5 (TEST) + 0

Keypad will beep every 40 seconds

Open sensors and keypad will sound

End test with 4-digit Code + 1 (OFF) key

(Wireless motions require no movement for 4 minutes prior to testing)

View Time/Date (Alpha Keypads only) Master Code + # + 63  
(Stays on for 30 seconds)

Set Time/Date (Alpha keypads will display menu, standard keypad will show nothing)

(WARNING: Do not set clock for 01/01/03 to 08/31/01 or panel cannot be downloaded!)

1. User Code + # + 63
2. Press \* within 30 seconds
3. Enter 2-digit Hour (00 to 12)
4. Enter 2-digit Minute (00 to 59)
5. Press 1 for PM, press 2 for AM
6. Enter last 2 digits of Year (01 to ??)
7. Enter 2-digit Month
8. Enter 2-digit Day
9. Press \* to exit or wait 10 seconds (Keypad will not give any confirmation beep)